


**FIG. 2**




REF. NO.	PART. NO.	QUANTITY				NOTE
		C26	EC34	HO25	TJ27	
1	752890		1			
5	480600		1			
6	090010		4			
7	030090		4			
9	752830	1		1	1	
10	120070	1	1	1	1	
11	270240	1	2	1	1	
12	120020	1	1	1	1	
13	480590	1		1	1	
14	481110	1	1	1	1	
15	481120	1	1	1	1	
16	544250	1	1	1	1	
17	030380	2	2	2	2	
18	060100	2	2	2	2	
19	725710	1	1	1	1	
21	030380	4		4	4	
22	090830	4		4	4	
23	752770	1	1	1	1	
24	544210	1	1	1	1	
25	752780	1	1	1	1	
26	540690	1	1	1	1	
27	391700	1	1	1	1	
28	030810	4	4	4	4	

REF. NO.	PART. NO.	QUANTITY				NOTE
		C26	EC34	HO25	TJ27	
29	090040	4	4	4	4	
30	542430	1	1	1	1	
31	060130	8	8	8	8	
32	542440	1	1	1	1	
33	542450	1	1	1	1	
34	030630	4	4	4	4	
35	722620	1	1	1	1	
36	511030	2	2	2	2	
37	570670	1	1	1	1	
38	543490	1	1	1	1	
39	724120	1	1	1	1	
40	540560	1	1	1	1	
41	543390	1	1	1	1	
42	030620	4	4	4	4	
43	090780	4	4	4	4	
44	060100	4	4	4	4	
45	724570	1	1	1	1	
46	753010	1	1	1	1	
47	570530	1	1	1	1	
48	542420	1	1	1	1	
49	722830	1	1	1	1	
50	753020	1	1	1	1	
51	752810	1	1	1	1	

# Parts and list

engine Diagram



Parts and list

E 26

No.	Part No.	Description	Qty
1	E26001	Cylinder	1
2	E26002	Cylinder gasket	1
3	E26003	Flat washer 5	2
4	E26004	Spring washer 5	2
5	E26005	Screw M5x22	2
6	E26006	Carburetor connector gasket	1
7	E26007	Carburetor connector	1
8	E26008	Screw M5x20	2
9	E26009	Carburetor gasket	1
10	E26010	Carburetor VER 332430	1
11	E26011	Choke lever	1
12	E26012	Bush	1
13	E26013	Air filter seat	1
14	E26014	Choke	1
15	E26015	Screw ST 4.2x12(F)	1
16	E26016	Carburetor screw M5x54	2
17	E26017	Air filter element	1
18	E26018	Air filter cover	1
19	E26019	Cover screw M4	1
20	E26020	Exhaust gasket	2
21	E26021	Heat insulating plate	1
22	E26022	Muffler	1
23	E26023a	Muffler screw M5x50	2
	E26023b	Flat washer 5	2
	E26023c	Spring washer 5	2
24	E26024	Heat insulating plate	1
25	E26025	Screw M4x16	1
26	E26026	Screw M4x12	1
27	E26027	Cylinder protector	1
28	E26028	Press plate	1
29	E26029	Screw M5x14	1
31	E26031	Spark plug	1
32	E26032	Water proof cap	1
33	E26033	Spark plug cap	1
34	E26034	Spring in spark plug cap	1
35	E26035	Position limit	1
36	E26036	Cover	1
37	E26037	Screw ST 4.2x16(F)	2
38	E26038 VER	Screw M5x20 030120	4
39	E26039	TCI	1
40	E26040	Screw M4x20	2
41	E26041	Clutch pin screw M6	2
43	E26043	Clutch	2
44	E26044	Clutch spring	1

No.	Part No.	Description	Qty
45	E26045	Washer 6	2
46	E26046	Flywheel nut M8	1
47	E26047	Flywheel	1
48	E26048	Screw M5x14	1
49	E26049	Plate	1
50	E26050	Crankcase screw M5x30	4
51	E26051	Oil seal 12x28x7	1
52	E26052	Crankcase(A)	1
53	E26053	Dowel pin $\varnothing 3 \times 10$	2
54	E26054	Crankcase gasket	1
55	E26055	Bearing clip 28	1
56	E26056	Bearing 6001	2
57	E26057	Piston rings	2
58	E26058	Piston	1
59	E26059	Needle bearing	1
60	E26060	Piston pin	1
61	E26061	Wearing bush	2
62	E26062	Clip for piston pin	2
63	E26063	Key 3x3.7x10	1
64	E26064	Crankshaft and connecting rod assembly	1
65	E26065	Oil seal 12x22x7	1
66	E26066	Crankcase(B)	1
67	E26067	Start bush	1
68	E26068	Spring	1
69	E26069	Starting pawl	1
70	E26070	Pushing plate	1
71	E26071	Rope handle	1
72	E26072	Rope	1
73	E26073	Screw	1
74	E26074	Reel	1
75	E26075	Spiral spring	1
76	E26076	Starter case	1
77	E26077	Sticker	1
78	E26078	Screw M4x16	4
79	E26079	One-way valve cover	1
80	E26080	Valve body	1
81	E26081	Vave seat	1
82	E26082	Fuel hose clip	1
83	E26083	Vent hose	1
84	E26084	Fuel back hose	1
85	E26085	Fuel hose	1
86	E26086	Fuel seal	1
87	E26087	Fuel hose clip	1
88	E26088	Filter	1
89	E26089	Fuel tank cap	1
90	E26090	Tank cap seal	1
91	E26091	Fuel tank	1
92	E26092	Screw M5x16	3