



<http://machinery.sumec.com/>

Ref. No.	Part No.	Description		Qty.
1-1	ST160F--1070200	Fuel tank comp	油箱组件	1
1-2	ST168F-1070006A	Oil filter	滤油网	1
1-3	ST168F-1070006B	Oil filter support	油箱滤网支架	1
1-4	ST160F-1070100H	Fuel filler cap comp	油箱盖	1
1-5	ST160F--1070300	Fuel tank joint	油管接头	1
1-6	ST160F--1070002	Tube	油管9X140	1
	ST160F-1070003	Tube cover	输油管保护套110	1
1-7	ST160F--1070001	clip	卡箍(I)	2
1-8	GB5789--86 M6×29	Flange bolt M6×29	螺栓M6×29	1
1-9	GB6177--86 M6	Nut M6	螺母M6	2

Ref. No.	Part No.	Description		Qty.
2-1	ST160F--1101200	Muffler comp	消声器组合	1
2-2	ST160F--1101100	Muffler protector	消声器保护罩	1
2-3	GB818--85 M5×8	Screw M5×8	螺钉M5×8	4
	GB93B Φ5	Flexibility gasket Φ5	弹垫Φ5	4
	GB6175 Φ5	Flat pad Φ5	平垫Φ5	4
2-4	GB6170--86 M8	Nut M8	螺母 M8	2
	GB93B Φ8	Flexibility gasket Φ8	弹垫Φ8	2
	GB6175 Φ8	Flat pad Φ8	平垫Φ8	2
2-5	ST160F-1100100	Muffler packing	消声器垫片	1

Ref. No.	Part No.	Description		Qty.
4-1	ST160F-1090200	Air cleaner elbow comp	空滤器底座	1
4-2	ST160F-1090003	Air cleaner grid	滤芯压板	1
4-3	ST160F-1090002	Air cleaner element	滤芯	1
4-4	ST160F-1090001	Air cleaner cover	滤芯壳	1
4-5	ST160F-1090100	Air cleaner cap comp	压盘组件	1
4-6	GB62-88	Air cleaner cover nut	蝶形螺母	1
4-7	GB6177--86 M6	Nut M6	螺母 M6	2

Ref. No.	Part No.	Description		Qty.
5-1	ST160F--1121000	Switch	熄火开关	1

Ref. No.	Part No.	Description		Qty.
6-1	ST160F--1130004	Air cleaner gasket	空滤器链接垫片	1
6-2	ST160F-1130100	Choke lever comp	风门杆	1
6-3	ST160F-1131000	Carburetor	化油器组合	1
6-4	ST160F-1130003	Carburetor gasket	化油器垫片	1
6-5	ST160F-1130001	Carburetor insulator	化油器隔温板	1
6-6	ST160F-1130002	Insulator packing	化油器隔温板垫片	1

Ref. No.	Part No.	Description		Qty.
9-1	ST160F-1050200	Crankshaft comp	曲轴组件	1
9-2	GB1099--79	Key	半圆键4X7.5X19	1
9-3	ST160F--1050100	Connecting rod comp	连杆组件	1
9-4	ST160F--1050004	Piston	活塞	1
9-5	ST160F--1050003	Piston pin	活塞销	1
9-6	139FMD-1004006	Piston pin clip	活塞销卡环	2
9-7	ST160F--1050007	First ring set	活塞环组合	1
	ST160F--1050006	Second ring set		1
	ST160F--1050200	Ring comp		1

尼龙棘爪拉盘

Ref. No.	Part No.	Description		Qty.
11-1	ST160F--1080001	Cooling fan	风扇	1
11-2	ST160F--1120100	Fly wheel	飞轮	1
11-3	ST160F-1123000	ignitor	高压包组合	1
11-4	GB5789--86 M 6X25	Flange bolt M 6X25	螺栓M 6X25	2
11-5	F6TC	Spark plug	火花塞 F6TC	1
11-6	ST160F--1050010	Nut M14	螺母	1
11-7	ST160F--1060001	Start hub	起动罩	1

尼龙棘爪拉盘

Ref. No.	Part No.	Description		Qty.
7-1	ST160F--1061006	Recoil starter knob	手柄	1
7-2	ST160F--1061100	Recoil starter comp	起动脉盖	1
7-3	ST160F--1061005	Recoil starter spring	回位弹簧	1
7-4	ST160F--1061009	Recoil starter rope	拉绳 ϕ 5X1300	1
7-5	ST160F--1061001	Recoil starter reel	拉绳盘	1
7-6	ST160F--1061004	Return spring	棘爪弹簧	2
7-7	ST160F--1061002	Starter ratchet	起动脉爪	2
7-8	ST160F--1061007	Ratchet guide	压板	1
7-9	ST160F--1061008	Setting screw	压板螺钉	1
7-10	ST160F--1080100	Fan cover comp	风扇罩组件	1
7-11	ST160F--1061003	Ratchet guide clip	压板卡簧	1
7-12	GB5789--86 M6X12	Flange bolt M6X12	螺栓M6X12	4
7-13	GB5789--86 M6X8	Flange bolt M6X8	螺栓M6X8	3

铁棘爪

Ref. No.	Part No.	Description		Qty.
11-1	ST160F--1080001	Cooling fan	风扇	1
11-2	ST160F--1120100	Fly wheel	飞轮	1
11-3	ST160F-1123000	ignitor	高压包组合	1
11-4	GB5789--86 M6X25	Flange bolt M6X25	螺栓M6X25	2
11-5	F6TC	Spark plug	火花塞 F6TC	1
11-6	ST160F--1050010	Nut M14	螺母	1
11-7	ST160F-1060001A	Start hub	起动罩	1

铁棘爪

Ref. No.	Part No.	Description		Qty.
7-1	ST160F--1061006	Recoil starter knob	手柄	1
7-2	ST160F-1061100A	Recoil starter comp	启动端盖	1
7-3	ST160F--1061005	Recoil starter spring	回位弹簧	1
7-4	ST160F--1061009	Recoil starter rope	拉绳 ϕ 5X1300	1
7-5	ST160F-1061001A	Recoil starter reel	拉绳盘	1
7-6	ST188F-1060006	Return spring	棘爪弹簧	2
7-7	ST188F-1060004	Ratchet guide spring	压板弹簧	1
7-8	ST188F-1060005	Starter ratchet	棘爪	2
7-9	ST188F-1060003	Ratchet guide	压板	1
7-10	ST188F-1060002	Setting screw	压板螺栓	1
7-11	ST168F--1080100	Fan cover comp	风扇罩组件	1
7-12	GB5789--86 M6X12	Flange bolt M6X12	螺栓M6X12	4
7-13	GB5789--86 M6X8	Flange bolt M6X8	螺栓M6X8	3

启动端盖分铁棘爪和尼龙棘爪两种，邵通的两种编号一一一致，都为ST160G-1061100

Ref. No.	Part No.	Description		Qty.
8-1	GB5789--86 M6X12	Flange bolt M6X12	螺栓M6X12	5
8-2	ST160F--1080003	Side place	导风罩组件（II）	1
8-3	ST160F-1030200	Oil seal	油封22×35×6	1
8-4	ST160F-1080005	Diode base comp	二极管支架组件	1
8-5	ST160F-1126000	Diode comp	二极管组件	1
8-6	ST160F--1030003	Drain plug bolt	放油螺栓	2
8-7	ST160F--1030004	Drain bolt washer	放油螺栓垫片	2
8-8	ST160F--1030012	Crankcase	箱体	1
8-9	GB/T—276--94	Radial ball bearing 6222	轴承	2
8-10	ST160F-1127000	Oil level switch assy	断油保护器	1
8-11	ST160F--1030008	Case over packing	箱体纸垫	1
8-12	ST160F--1030001	Oil filler cap assembly	量油尺	2
8-13	ST160F--1030002	Oil filler cap packing	量油尺垫片	1
8-14	ST160F--1030007	Crankcase cover	箱盖	1
8-15	GB5789--86 M6×29	Flange bolt M6×29	螺栓M6×29	6
8-16	ST160F-1030100	Oil seal	油封22×41.3×6	1
8-17	ST160F--1030005	Oil filler cap	机油塞	1
8-18	ST160F--1080002	Shroud comp	导风罩（I）	1
8-19	GB5789--86 M6X8	Flange bolt M6X8	螺栓M6X8	2
8-20	139FMD-1001001	Dowel pin 8*14	定位销	2
8-21	GB5789--86 M8X55	Flange bolt M8X55	螺栓M8X55	4

Ref. No.	Part No.	Description		Qty.
10-1	ST160F--1110101	Governor weight holder	调速齿轮	1
10-2	ST160F--1110102	Governor weight pin	离心块销	2
10-3	ST160F--1110104	Governor shaft	调速齿轮轴	1
10-4	ST160F--1110103	Governor holder clip	调速齿轮轴卡簧	1
10-5	ST160F--1110107	Governor weight	离心块	2
10-6	ST160F--1110106	Governor shaft washer	调速齿轮内垫片	1
10-7	ST160F--1110105	Governor cover	调速齿轮轴套	1
10-8	ST160F--1111000	Control assembly	调速器	1
10-9	GB5789--86 M6X12	Flange bolt M6X12	螺栓M6X12	2
10-10	ST160F--1110004	Governor arm bolt	调节臂螺栓	1
10-11	ST160F--1110006	Governor rod	调速拉杆	1
10-12	ST160F--1110005	Throttle return spring	细弹簧	1
10-13	ST160F--1110007	Governor spring	调速弹簧	1
10-14	ST160F--1110003	Governor arm	调节臂	1
10-15	GB6177--86 M6	Nut M6	螺母M6	1
10-16	ST160F--1110008	Lock pin	弹性销	1
10-17	ST160F-1110002	Washer	摇杆垫片	1
10-18	ST160F--1110001	Governor arm shaft	摇杆	1
10-19	ST160F-1110108	Washer 6.4×13×1	调速齿轮垫圈 II	1

Ref. No.	Part No.	Description		Qty.
12-1	ST160F--1041000	Camshaft assembly	凸轮轴	1

12-2	ST160F--1040013	Valve lifter	挺柱	2
12-3	ST160F--1040002	Intake valve	进气门	1
12-4	ST160F--1040006	Exhaust valve	排气门	1
12-5	ST160F--1030009	Cylinder head gasket	气缸盖垫片	1
12-6	ST160F-1010002	Stud bolt	双头螺柱M8X35	2
12-7	ST160F--1010100	Cylinder head comp	气缸盖组件	1
12-8	ST160F--1040005	Push rod	推杆	2
12-9	ST160F-1040004-A	Push rod guide plate	推杆导向板	1
12-10	ST160F--1040010	Pivot bolt	摇臂螺栓	2
12-11	ST160F--1040009	Valve rocker arm	摇臂	2
12-12	ST160F--1040012	Rocker arm pivot	调整螺母	2
12-13	ST160F--1040011	Pivot adjusting nut	锁紧螺母	2
12-14	GB5789--86 M6X12	Flange bolt M6X12	螺栓M6X12	4
12-15	ST160F--1020100	Head over comp	气缸盖罩组件	1
12-16	ST160F--1020001	Breather tube	通气管	1
12-17	ST160F--1020002	Head over packing	气缸盖垫片	1
12-18	ST160F--1040008	Valve rotator	排气门帽	1
12-19	ST160F--1040001	Intake valve spring retainer	进气门上座	1
12-20	ST160F--1040007	Exhaust valve spring retainer	排气门上座	1
12-21	ST160F--1040003	Valve spring	气门弹簧	2
12-22	ST168F-1010001-A	Stud bolt 6*113	螺栓M6X113	2
12-23	152FMD--1001007	Dowel pin 10*16	定位销	2
12-24	ST168F-1040014	Valve oil	气门油封	2



